

# KeedeBand™



## DESCRIPTION

Dependable's KeedeBand™ is a triple layer waterproofing band designed for the KeedeRoll 300 uncoupling mat. It is designed to be used under the seams and the perimeter of the wall where of KeedeRoll 300 is used. KeedeBand completes the waterproofing system of the Dependable KeedeRoll 300™.

## APPLICATIONS

- Where KeedeRoll 300 needs waterproofing
- Below KeedeRoll 300
- Around the perimeter of a room where KeedeRoll 300 is installed.

## FEATURES AND BENEFITS

- Waterproof fabric
- Double laminated
- 5" width for easy installation

## PACKAGING

- 50' LF
- 5" Wide

## PHYSICAL CHARACTERISTICS

A 5" wide roll on a 3" core consisting of 50 Liner Feet.

## MATERIAL AND STORAGE REQUIREMENTS

1. Deliver and keep materials in original packaging until ready to use.
2. All claims of damage must be reported to the freight company. Report any defects in material to Dependable immediately.

## FLOOR REQUIREMENTS

### WOOD

OSB and plywood are approved substrates for KeedeRoll™ 300 and KeedeBand™. Ensure the flooring is structurally sound and built to code, with movement joists placed in accordance with industry standards.

## FLOOR REQUIREMENTS

### Substrate Preparation

- Ensure the subfloor is properly fastened, structurally sound and built to code.
- Clear any dust, paint, oil, wax or potential bond breaker from the floor. Consult Dependable Technical Services if you have any questions.
- The subfloor MUST be flat and level. If leveling is required use a Dependable self-leveler or patching product such as Skimflow ES or Skimcrete XL. Consult the product's data sheet for details.

### Approved Thin-sets and Grouts

- Any modified thin-set in accordance with ANSI A118.14 or ANSI A118.11.
- Any unmodified thin-set in accordance with ANSI A118.1.

### CONCRETE

Concrete is an approved substrate for KeedeRoll, ensure it's structurally sound prior to installation.

### KeedeBand Installation

Follow these steps for waterproofing only

- Apply thin-set at the wall joints.
- Place KeedeRoll 300 5" waterproofing band (KeedeBand) in the center between the wall and floor.
- Trace additional thin-set over the tape using the flat side of the trowel ensuring 100% bond and no excess mortar or air pockets.
- Install KeedeRoll 300 per instructions on KeedeRoll 300 technical data sheet.
- Place additional tape below where one roll ends and a new roll begins, and where no selvage edge is provided. Secure with mortar on top and bottom. Cover with KeedeRoll 300.

Technical Assistance: Visit our website: [floorprep.com](http://floorprep.com) or call 1-800-227-3434

### LIMITED WARRANTY:

For information about the warranty please visit our website at [www.floorprep.com](http://www.floorprep.com) or contact us at 1-800-227-3434.



P.O. Box 16307

Rocky River, OH 44116

info@dependable.us

[www.floorprep.com](http://www.floorprep.com)



800 | 227 | 3434

P 440 | 333 | 1123

F 440 | 333 | 0070