



## Dependable, LLC

---

P.O. Box 241354 • Mayfield Heights, OH 44124 • Tel 800-227-3434 • Fax 440-333-3781

---

# Technical Bulletin SCXL-1-97

## SKIMCRETE® XL Over Cut Back Emulsion

Dependable SKIMCRETE® XL (trowelable portland cement based underlayment) may be applied over old cut back emulsion prior to installing a new floor system by following the steps outlined below.

1. Sweep or vacuum any loose material and dirt off the floor prior to patching.
2. Do a test patch on the cleaned floor.
3. Brush coat Dependable ACRYLIC EMBOSSING ADDITIVE™ (full strength) over an area approximately one square foot (larger if desired). Let dry until at least tacky. Mix SKIMCRETE® XL into water or ACRYLIC EMBOSSING ADDITIVE™ and trowel over the additive brush coat.
4. Give the test area two to three hours to cure. Check the bond.
5. Once you have determined you have a satisfactory bond, prime and patch the balance of the floor. ***If you are not satisfied with the test results DO NOT continue with the SKIMCRETE® XL.***

Always allow sufficient time for the SKIMCRETE® XL to dry before applying adhesives and/or new floor covering over it.

If you have any questions or comments with respect to this technical bulletin, please contact technical service at Dependable, LLC at 1-800-227-3434.