



Dependable, LLC

P.O. Box 241354 • Mayfield Heights, OH 44124 • Tel 800-227-3434 • Fax 440-333-3781

Technical Bulletin WSC-2-99

WHITE SKIMCOAT™ Over Cut Back Emulsion

Dependable WHITE SKIMCOAT™ Underlayment may be applied over old cut back emulsion prior to installing a new floor system by following the steps outlined below.

1. Do a test patch on the cleaned floor. Brush coat Dependable ACRYLIC EMBOSSING ADDITIVE™ (full strength) over an area approximately one square foot (larger if desired). Mix WHITE SKIMCOAT™ into ACRYLIC EMBOSSING ADDITIVE™ then trowel over the latex brush coat.
2. Give the test area two to three hours to cure. Check the bond.
3. Once you have determined you have a satisfactory bond, prime and patch the balance of the floor. ***If you are not satisfied with the test results DO NOT continue with the WHITE SKIMCOAT™, contact Dependable Technical Services at 800-227-3434.***

If a second application of WHITE SKIMCOAT™ is to be applied over the first application, wait at least two hours before applying to be sure the application has completely dried.

NOTE: For this application, only ACRYLIC EMBOSSING ADDITIVE™ should be used with Dependable WHITE SKIMCOAT™ Underlayment. The ACRYLIC EMBOSSING ADDITIVE™ should never be diluted as it will affect the mildewcide and the rubber solids.

We have every reason to believe that if the above instructions are followed, with special emphasis on doing a **TEST PATCH** prior to beginning the patching portion of the installation you will be sufficiently informed to make a qualified judgement as to how well the WHITE SKIMCOAT™ and ACRYLIC EMBOSSING ADDITIVE™ will work.

Always allow sufficient time for the WHITE SKIMCOAT™ to dry **before** applying a second application or **before** applying adhesives over it.

If you have any questions or comments with respect to this technical bulletin, please contact technical service at Dependable, LLC at 1-800-227-3434.