

# WATERPROOF UNCOUPLING MEMBRANE

## KEEDEROLL™ 300



### DIVISION

Division 9  
Tile Finishes 09 30 95  
Acoustical Treatments 09  
800

### PACKAGING

KeedeRoll™ 300  
60 square feet roll  
- 4 ft. width  
- 15 ft. length  
- 9 lbs/roll  
200 square feet roll  
- 4 ft. width  
- 50 ft. length  
- 30 lbs/roll

### APPROVED SUBSTRATES

- Plywood or OSB subfloors
- Dependable's patches and self-levelers
- Concrete
- Radiant heat flooring

### LEED v4

LEED v4 BD+C (Building Design + Construction)

MR Credit 3: 1-2 points  
(Material & Resources)  
Building Product Disclosure and Optimization - Sourcing of Raw Materials

Locally sourced materials and recycled content are now combined in

- 2 options:
1. Raw Material Source and Extraction Reporting (1 point)
  2. Leadership Extraction Practices (1 point)
- Low Emitting Materials  
VOC content 0g/l (calculated)  
Recycled Content up to 40%

*Please refer to Dependable's LEED Brochure for more information.*

FloorPrep's uncoupling mat provides a fast, durable and cost effective solution for tile installation. KeedeRoll™ 300's technology works by absorbing subfloor movements and reinforcing mortar; while the fabric allows for shearing movement to take place by separating the subfloor from the tile or natural stone. KeedeRoll™ 300 is an ideal product for plywood substrates providing both reinforcement and water protection using a laminate water resistant fabric. KeedeRoll™ 300 is designed to keep their durability for years to come.

## Features

- Crack isolation protection
- Water resistant
- Strengthens wood substrate
- Easy to install
- Light weight
- High compressive strength
- Increases tensile strength
- Reinforcement for mortar
- High point load strength

## Characteristics

A geometrically shaped roll with entangled net bonded to fabric.

## Floor Requirements

### WOOD

OSB and plywood are approved substrates for KeedeRoll™ 300. Ensure the flooring is structurally sound and built to code, with movement joists placed in accordance with industry standards.

### Joist

- For a 16" o.c. joist, I-joist, or floor truss, use a minimum subfloor thickness of 5/8" (16 mm).  
Tongue-and-groove with a 1/8" (3 mm) gap between sheets.
- For a 19.2" o.c. joist, I-joist, or floor truss, use a minimum subfloor thickness of 3/4" (19 mm).  
Tongue-and-groove with a 1/8" (3 mm) gap between sheets.
- For 24" o.c. I-joist, or floor truss, use a double layer of plywood. Use a minimum subfloor thickness of 3/4"(19 mm) and an added layer of 3/8" (10 mm) subfloor as a second layer.

### Substrate Preparation

- Ensure the subfloor is properly fastened, structurally sound and built to code.
- Clear any dust, paint, oil, wax or potential bond breaker from the floor. Consult Dependable Technical Services if you have any questions.
- The subfloor MUST be flat and level. If leveling is required use a Dependable self-leveler or patching product. Dependable's SKIMFLOW® ES or SKIMFLOW® HPI is recommended. Consult the product's data sheet for details.

### Approved Thin-sets and Grouts

- Any modified thin-set in accordance with ANSI A118.14 or ANSI A118.11.
- Any unmodified thin-set in accordance with ANSI A118.1.
- Use of a modified thin-set is recommended.

### CONCRETE

Concrete is an approved substrate for KeedeRoll™, ensure it's structurally sound prior to installation. Additionally, ensure the slab meets TCNA requirements and temperature requirements.

## TESTING

1. ASTM C627 Robinson Wheel Test Rated Extra Heavy
2. 7 Day Shear Strength test 97 PSI Exceeds Standards

## MATERIAL AND STORAGE REQUIREMENTS

1. Deliver and keep materials in original packaging until ready to use.
2. All claims of damage must be reported to the freight company. Report any defects in material to Dependable immediately.

## FLOOR REQUIREMENTS Continued

### Substrate preparation:

- Ensure the substrate is structurally sound
- Clear any dust, paint, oil, wax or potential bond breaker from the floor. Consult Technical Services if you have any questions.
- The subfloor MUST be flat and level. If leveling is required use a Dependable self-leveler or patching product. If you're installing KeedeRoll™ on a gypsum concrete subfloor use Dependable's SKIMFLOW® HPI or WHITE SKIMCOAT (see data sheets for details). If you're installing KeedeRoll on a Portland concrete floor use Dependable's SKIMFLOW® ES and FEATHERCRETE products (see data sheets for details).
- Assure that the RH level of the concrete slab is in accordance with the finished floor's tolerance level. Consult the manufacturer's instructions. Use ASTM F2170 Standard Test Method for determining RH in concrete slabs to determine RH levels. (Note: this is not required for gypsum concrete).
- If the concrete slab exhibits any cracking, ensure the cracks are in-plane. If the cracks are NOT in-plane, do NOT install KeedeRoll™.

### Movement Joints:

Movement joints must be installed in accordance with industry standards, if they are not do NOT install KeedeRoll™.

### HEATED FLOORS

Heated floors are an approved substrate for KeedeRoll™. Ensure the heated floor is either an electric thin mat or wire heating floor system. Follow the manufacturer's installation instructions, and follow KeedeRoll's installation instructions for wood substrates above.

### REQUIRED TOOLS:

- 1.4" or V-notch trowel
- Appropriate thin-set mortar (see Approved Thin-Set's and Grouts above)
- Carpet knife
- Tile float or roller

## KEEDEROLL 300 INSTALLATION INSTRUCTIONS

Following the steps properly while installing KeedeRoll is essential to the success of your installation. For further details on uncoupling membrane installations consult TCNA manual methods F147-14, F148-14, and F128-14.

- Mix mortar according to the manufacturer's instructions on the looser side.
- Starting from the wall and using the appropriate thin-set mortar begin troweling out the mortar using a 1/4" x 3/16" V-notch trowel.
- Trowel enough area to cover with a portion of KeedeRoll™ then work your way down while rolling out the mat.
- Place KeedeRoll™ into the mortar with the fabric side down with the selvedge edge exposed and away from the wall. Use a float trowel or roller to ensure that the fabric is embedded to the mortar. Roll the area until any air pockets are eliminated.
- Lift up a corner to ensure there is full coverage of thin-set mortar on the fabric.
- Align the end and side sections of KeedeRoll™ and apply mortar to the selvedge edge and subfloor. Roll the product out as done previously. Continue working the product out while making sure the joints are butted tightly and the selvedge edge is covered. Continue this pattern until the area is complete.
- At roll ends or butt joints place a piece of scrap KeedeRoll™ fabric with the core removed from it under both pieces and trowel or roll into the thin-set mortar. Place additional mortar on the fabric and continue with the installation, assuring the fabric covers the entire seam edge.

### Installing Tile over KeedeRoll™

All tile must be installed according to the tile manufacturers recommended installation instructions.

- Tile may be installed over KeedeRoll™ as soon as KeedeRoll™ has been installed and embedded into place.
- Trowel the appropriate mortar using the appropriate size trowel recommended by the tile manufacturer depending on the tile size.
- Ensure the mortar has filled the entangled net and encased into the filaments.
- Embed the tiles into the setting materials. Periodically lift the tile to make sure the tile has appropriate coverage.

**LIMITED WARRANTY:**

Dependable, LLC warrants to the initial purchaser only that the goods sold hereunder will be free from defects in material and workmanship and, except as otherwise set forth herein, will conform to the specifications provided. If any failure to meet this warranty appears within one year from the date of shipment of the goods, on the condition that Dependable, LLC. will correct any such failure by either replacing or repairing any defective goods, at Dependable, LLC's option.

The preceding paragraph sets forth the exclusive remedy for all claims based on failure of or defect in the goods sold hereunder, whether such failure or defect arises before or during the warranty period and whether a claim, however instituted, is based on contract, indemnity, warranty, tort (including negligence), strict liability or otherwise. The forgoing warranty is exclusive and is in lieu of all other warranties whether written, oral, implied or statutory.

**24 HOUR EMERGENCY:  
CHEMTREC®  
1-800-424-9300  
NON-TOXIC and  
NON-FLAMMABLE**

Keep container closed and keep away from children. May cause slight eye abrasion or irritation if spilled or rubbed in eyes. Flush thoroughly with water.

If taken internally, call a physician. Technical Assistance:  
Visit our website: [floorprep.com](http://floorprep.com) or call 1-800-227-3434.

**KEEDEROLL 300 INSTALLATION INSTRUCTIONS Continued**

**Waterproofing Installation**

**Follow these steps for waterproofing only**

- Apply thin-set at the wall joints.
- Place KeedeRoll™ 300 5" waterproofing band (KeedeBand) in the center between the wall and floor.
- Trace additional thin-set over the tape using the flat side of the trowel ensuring 100% bond and no excess mortar or air pockets.
- Place additional tape below where one roll ends and a new roll begins, and where no selvage edge is provided. Secure with mortar on top and bottom. Cover with KeedeRoll™ 300.

**LIMITATIONS**

- This product is not intended for use in areas with standing water.
- This is including but not limited to fountains, pools, and tiled tubs. This product is not intended to be used as a wear surface.
- Always follow TCNA guidelines when installing KeedeRoll™.



Flooring Experts since 1951



**info@dependable.us** 800 | 227 | 3434  
**floorprep.com** P 440 | 333 | 1123  
F 440 | 333 | 3781

2020/7  
3/3